




## Report Wizard


01.14.2020  
version 5.3

This step-by-step tutorial is designed to cover SDC Verifier topics, namely :

- ▶ Add new report;
- ▶ First page settings;
- ▶ Model entities in report;
- ▶ Operations with tables and plots;
- ▶ Include results of the standards;
- ▶ Report generation.


# Open Project

- 1 Launch **SDC Verifier** 
- 2 Execute *File - Open Project*.
- 3 Project: **Report\_Wizard\_Tutorial .sdcv**



# Add New Report

1 Execute **Reports** – **Add** – **Empty** from report context menu



There are 4 templates of reports:

**Empty** – only first page and preface items are included;

**Model Setup** – description of model data (materials, properties, components, boundary conditions) is included;

**Results** – for each load extreme displacement tables, stress and displacement plots are included. Predefined tables: sum of reaction forces, stresses/displacements summary tables;

**Full** – Model Setup + Results + all tables created in Job.

# Report Wizard Window

1. Save changes to current report. If report is not saved – new report will be added

2. Add new report to the project

3. Open report settings

4. Open unit system

5. Open legend settings

6. Open number format settings

7. Modify components of the project

8. Modify views of the project

9. Export all Plots created in report to the project

10. Export all Tables created in report to the project

Navigation between report wizard sections

**Add Report Wizard**

**First Page**  
Define Executor, Client information and Project details

ID: 1 Title: Report

Description: [Text Box]

**Engineer details**  
Engineer: [Text Box]  
Company: [Text Box]  
E-mail: [Text Box]  
Phone: [Text Box]  
Address: [Text Box]  
Web Site: [Text Box]  
Logo: [Image Box]

**Customer details**  
Contact Person: [Text Box]  
Company: [Text Box]  
E-mail: [Text Box]  
Phone: [Text Box]  
Address: [Text Box]  
Web Site: [Text Box]  
Logo: [Image Box]

**Project Details**  
Number: [Text Box] Version: 1  
Name: kocks6000\_example

**Navigation**  
First Page  
Model Setup  
Job Settings & Tools  
Tables  
Plots  
Standards

**Image**  
From file: [Image Box]  
From View: 1. Default View

**Buttons:** < Back, Next >, OK, Generate, Go To Designer, Close

Step to next / previous section of report wizard

Generate the report and export to MS Word

Close current report and open Report Designer window to customize the report structure

# Report Settings


Include directions in Tables enables to change visibility of directions in tables by categories:

Stress Extreme (All Entities)

Individual Load Type	1..gravity Extreme	Selection Parameter	All Entities Stress	
Extreme	X	Y	XY	Equivalent
Minimum	-83.29e+6		0.00e+6	0.00e+6
Maximum	68.53e+6		0.00e+6	83.29e+6
Absolute	-83.29e+6		0.00e+6	83.29e+6


Skip empty plots: if a plot does not contain values that pass the limit, it will not be generated and warning message will be displayed

View is applied to plots of the model entities (Materials, Properties etc.)




Usm Displacement (All Entities, 1..Default View)

Setting OFF





Setting ON



Show displacement without Contour: no legend and only deformation will be displayed on the plot

# First Page Settings


1 Press  and select Support Engineer from the library

2 Press  and select Customer from the library

3 Image – **From View: 1..Default View**

4 Press *Next*.

Use *Navigation* alternatively



**Add Report Wizard**

**First Page**  
Define Executor, Client information and Project details

**Navigation**

- First Page
- Model Setup
- Job Settings & Tools
- Tables
- Plots
- Standards

ID: 1 Title: Report

Description:

**Engineer details**

1. Engineer: Support


Company: SDC Verifier

E-mail: support@sdcsverifier.com

Phone: +31 15 30-10-310

Address: Zijlvest 25 [...]

Web Site: sdcsverifier.com

Logo: 

☐ Put logo on report plots

**Customer details**

2. Contact Person: customer

Company: company

E-mail: customer@company.com

Phone: +31 15 555-55-55

Address: Zijlvest 25 [...]

Web Site: company.com


Logo: 

Image: ☐ From file

3. ☒ From View: 1..Default View


Project Details

Number: Version: 1


Name: locks6000\_example

4. **Next >**

OK Generate Go To Designer Close

**Note:** The default data from library is used for Engineer and Customer. It is possible to fill in your data and store it to the library  to reuse it in the future projects.

# Generated First Page





# Model Setup Section

1 Model Information and Model Entities:  
**ON**

2 Press *Include Plots*

3 Press *Next* to navigate to Job Settings & Tools section

Use *Navigation* alternatively

Materials and properties information type will be changed from Brief to Full. Plots will be selected automatically for all enabled items.

*All / None* buttons – select/deselect all model entities (Materials, properties etc.)

1. Model Information and Model Entities: ON

2. Press *Include Plots*

3. Press *Next* to navigate to Job Settings & Tools section

Use *Navigation* alternatively

Materials and properties information type will be changed from Brief to Full. Plots will be selected automatically for all enabled items.

*All / None* buttons – select/deselect all model entities (Materials, properties etc.)

## Model Information

### Model Summary

Entity	Count
Mass [kg]	2017142.7
Gravity Center [m]	[-14.70; 0.00; 35.00]
X [Min:Max] [m]	[-80.48; 80.00]
Y [Min:Max] [m]	[-9.25; 9.25]
Z [Min:Max] [m]	[8.00; 70.00]

Properties Brief information

## Properties

This paragraph contains properties information.



### Properties Summary

Title	Elements	Material	Mass [kg]	Gravity Center [m]
1..portside legs	44	1..steel	112491.4	[-32.42; 0.00; 28.04]
2..sea side legs	44	1..steel	111564.2	[0.00; 0.00; 28.00]
3..stiffening beam	32	1..steel	24644.6	[-15.24; 0.00; 16.00]
4..cross members	78	1..steel	1183705.7	[-18.76; 0.00; 33.00]
5..chassis beam	22	1..steel	57799.6	[-15.24; 0.00; 6.00]
6..gantry members PS	10	1..steel	28899.8	[-35.48; 0.00; 50.00]
7..gantry members SS	10	1..steel	17357.3	[0.00; 0.00; 50.00]
8..top part	22	1..steel	13449.9	[0.00; 0.00; 60.00]
9..main beam	13	1..steel	58678.8	[-47.98; 0.00; 42.00]
10..between legs	18	1..steel	83276.9	[-17.74; 0.00; 42.00]
11..sea side	31	1..steel	140829.0	[30.00; 0.00; 42.00]
12..forestay	1	1..steel	21426.6	[22.50; 0.00; 56.00]
13..backstay	1	1..steel	18272.3	[-17.74; 0.00; 56.00]
14..Top stiffness member portal	36	1..steel	19249.8	[-17.74; 0.00; 50.00]
15..Top diagonal members	50	1..steel	19244.2	[-17.74; 0.00; 50.00]
16..Bridge_support_SS	4	1..steel	13126.5	[0.00; 0.00; 46.00]
17..Bridge support beam PS	4	1..steel	13126.5	[-35.48; 0.00; 46.00]
18..machine_house	1	2..Machine_house	79999.9	[-35.48; 0.00; 52.00]
Overall	421		2017142.7	[-14.70; 0.00; 35.00]

Properties Full information includes Brief and detailed information of each property

### 8..top part

Property	Value	Property Shape
Type / Elements	Beam / 22	
Material	1..steel	
Mass [kg]	13449.9	
Gravity Center [m]	[0.00; 0.00; 60.00]	
Area, [m^2]	0.03	
I1, [m^4]	3.811e-03	
I2, [m^4]	3.811e-03	
I12, [m^4]	0	
Torsion Constant, [m^4]	0.01	
Y Shear Area, [m^2]	0.02	
Z Shear Area, [m^2]	0.02	
Nonstructural Mass, [kg]	0	
Perimeter, [m]	3.14	
Warping Constant, [m^6]	0	
Y Neutral Axis Offset A, [m]	0	
Z Neutral Axis Offset A, [m]	0	
r [m]	0.500	
t [m]	0.010	



FEMAP


*Jobs:* **ON**

Press *All* to include all settings of the section

Settings will be included only for selected job. Other jobs have their own settings.

Press *Next* to navigate to the Tables section

## Use *Navigation* alternatively



**Job Description** includes information about the selected job (selection, requested results etc.) and list of used in Individual Loads FEM Loads and Constraints

**Plot Individual Load** – Each Individual load additionally will generate plot of related FEM Load and Constraint. Default View will be used for the plot

*Include Contents* – FEM Loads and Constraints for individual loads; Individual loads with factors for load sets; Loads with safety factors for load groups;

# Tables Section

1 Select all Individual loads from the list

2 Press  to add table

Add simple expand or extreme table by result categories

✓ Edit '1..Report 1'

**Navigation**

- First Page
- Model Setup
- Job Settings & Tools
- Tables**
- Plots
- Standards

**Tables**

Define Expand, Extreme and Output Vector Tables. Expand - detailed table with results on each entity from selection.  
Extreme - worst values on selection. Output Vector tables - expand table on output vectors.


✓ Jobs  Table Type

1.

Individual Loads	Tables
1..gravity	0
2..tip load	0
3..middle_bridge	0
4..back side	0
5..At_forestay	0
6..at_hinge_point	0
7..9Trolley_ride	0
8..tip side_load	0
9..middle_bridge_side_load	0
10..back side_side_load	0
11..At_forestay_side_load	0
12..at_hinge_point_side_load	0
13..Crane_ride	0

2.

Category	Type	Selection
----------	------	-----------



< Back Next > OK Generate Go To Designer Close

# Add Extreme Table

1

Select *Displacement* and *Stress* categories

2

Add all materials to selection list

3



Press *OK*

## Table Types:

**Expand** – display result for each element/node;  
**Extreme** – worst values on selection;

To include tables that contain more than 200 rows – change maximum rows count in report settings or turn off warning setting.

☒ Warning about rows count over limit



# Edit Tables Settings

Amount of created tables is a combination of categories, selections and types

Tables are created for all selected loads and common tables are displayed in the list

Individual Loads	Tables	Category	Type	Selection
1..gravity	6	Stress	Extreme	All Entities
2..tip load	6	Stress	Extreme	Material '1..steel'
3..middle_bridge	6	Stress	Extreme	Material '2..Machine_house'
4..back side	6	Displacement	Extreme	All Entities
5..At_forestay	6	Displacement	Extreme	Material '1..steel'
6..at_hinge_point	6	Displacement	Extreme	Material '2..Machine_house'
7..9Trolley_ride	6			
8..tip side_load	6			
9..middle_bridge_side_load	6			
10..back side_side_load	6			
11..At_forestay_side_load	6			
12..at_hinge_point_side_load	6			
13..Crane_ride	6			

Change category

Category	Type
Displacement	Extreme
Displacement	Extreme
Displacement	Extreme
Stress	Extreme
Stress	Extreme
Applied Force	Extreme
Reaction Force	Extreme

Change Type

Type	
Extreme	All Entities
Extreme	Expand
Extreme	Extreme
Extreme	Material '1..steel'
Extreme	Material '2..Machine_house'


Change Selection

Selection
All Entities
Material '1..steel'
Material '2..Machine_house'
All Entities
Material '1..steel'
Material '2..Machine_house'

Changes will be applied to all selected tables

# Add Output Vector Table

1

Press  to add output vector table(expand/extreme)

2

Press *Select* to add output vectors

3

Select **Element Stress**

4


Select **Beam stress vectors** and press 


5


Press *OK*.

6


Press *OK*

Press  to store predefined set of output vectors to the library.


Fill Custom ID and press  to add already known vector



1.



2.



5.

# Copy Tables

1 Select first individual load and select all tables from the list

2 Press 


3 Select *Table Type*: Load Sets


4 Select two first Load Sets in the list


5 Press 


Tables order will be kept


Output vector tables are available only for Individual Loads. For other types they will be skipped on copy.

1. 

2. 

3. 

4. 


5. 



# Add Flow Table

1. Select *Table Type*: Components and Flow Tables

2. Press  to add flow table





3. Press 

4. Press *LS* to add all Load Sets


5. Press *OK*


6. Press *OK*



# Add Components Table




1 Press Components Table



2 Press  and select **All Load Groups**


3 Add all properties to the selection list

4 Press OK



# Add Force Summation Table

1 Press Force Summation Table over Loads

2 Press  and select **All Individual Loads**


3 Press **All** to add the full model selection



4 Select categories: **Applied and Reaction forces**

5 Press **OK**

Current table is similar to the flow table, but instead of showing the worst (or detailed) results, forces are summarized on the full selection

Description
Abs Stress (20 Loads, All Entities)
Abs Stress (LG1, 18 Selections)

1. 





# Generated Tables

Advanced Tables are predefined tables that can be defined for all types of loads at once (Advanced Tables Overall) or each load separately (Advanced Tables For Each Load)

Absolute stress over all load sets

Abs Stress (20 Loads, All Entities )

Loads Count	20	Category	Stress	
Selection	All Entities	Type	Extreme	
Parameter	Abs			
Load	X [Pa]	Y [Pa]	XY [Pa]	Equivalent [Pa]
LS1..LC1s_Tip load.1	-176.40e+6		-0.02e+6	176.40e+6
LS2..LC1s_Tip load.2	-176.40e+6		0.02e+6	176.40e+6
LS3..LC1s_Tip load.3	-172.95e+6		-0.02e+6	172.95e+6
LS4..LC1s_Tip load.4	-172.95e+6		0.02e+6	172.95e+6
LS5..LC1s_Middle Bridge.1	-113.16e+6		0.00e+6	113.16e+6
LS6..LC1s_Middle Bridge.2	-113.16e+6		0.00e+6	113.16e+6
LS7..LC1s_Middle Bridge.3	-115.13e+6		0.00e+6	115.13e+6
LS8..LC1s_Middle Bridge.4	-115.13e+6		0.00e+6	115.13e+6
LS9..LC1s_Backside.1	139.42e+6		0.00e+6	139.42e+6
LS10..LC1s_Backside.2	139.42e+6		0.00e+6	139.42e+6
LS11..LC1s_Backside.3	142.59e+6		0.00e+6	142.59e+6
LS12..LC1s_Backside.4	142.59e+6		0.00e+6	142.59e+6
LS13..LC1s_At_forestay.1	-148.02e+6		-0.01e+6	148.02e+6
LS14..LC1s_At_forestay.2	-148.02e+6		0.01e+6	148.02e+6
LS15..LC1s_At_forestay.3	-144.57e+6		-0.01e+6	144.57e+6
LS16..LC1s_At_forestay.4	-144.57e+6		0.01e+6	144.57e+6
LS17..LC1s_at_hinge_point.1	148.51e+6		-0.01e+6	148.51e+6
LS18..LC1s_at_hinge_point.2	148.39e+6		0.01e+6	148.39e+6
LS19..LC1s_at_hinge_point.3	145.20e+6		-0.01e+6	145.20e+6
LS20..LC1s_at_hinge_point.4	145.09e+6		0.01e+6	145.09e+6

Absolute stress over properties for one load

Abs Stress (LG1, 18 Selections)

Load Group	1..Overall	Selections	18	
Type	Components Extreme	Parameter	Absolute Stress	
Components	X [Pa]	Y [Pa]	XY [Pa]	Equivalent [Pa]
Beam '1..portside legs'	-116.22e+6			116.22e+6
Beam '2..sea side legs'	-112.97e+6			112.97e+6
Beam '3..stiffening beam'	-115.13e+6			115.13e+6
Beam '4..cross members'	61.51e+6			61.51e+6
Beam '5..chassis beam'	67.57e+6			67.57e+6
Beam '6..gantry members PS'	142.59e+6			142.59e+6
Beam '7..gantry members SS'	148.51e+6			148.51e+6
Beam '8..top part'	-176.40e+6			176.40e+6
Beam '9..main beam'	-130.16e+6			130.16e+6
Beam '10..between legs'	-86.05e+6			86.05e+6
Beam '11..sea side'	-113.09e+6			113.09e+6
Rod '12..forestay'	137.87e+6		0.02e+6	137.87e+6
Rod '13..backstay'	148.06e+6		-0.01e+6	148.06e+6
Beam '14..Top stiffness member portal'	-102.12e+6			102.12e+6
Beam '15..Top diagonal members'	-84.51e+6			84.51e+6
Beam '16..Bridge_support_SS'	61.10e+6			61.10e+6
Beam '17..Bridge support beam PS'	97.41e+6			97.41e+6
Beam '18..machine_house'	-0.01e+6			0.01e+6

Sum of applied forces over all individual loads

Applied Force Summation (13 Loads, All Entities )

Loads Count	13	Category			Applied Force				
Selection	All Entities	Type			Expand				
Load		Fx [N]	Fy [N]	Fz [N]	Fsum [N]	Mx [N m]	My [N m]	Mz [N m]	Msum [N m]
IL1..gravity		0.0	0.0	-19788174.0	19788174.0	0.0	0.0	0.0	0.0
IL2..tip load		0.0	0.0	-1220000.0	1220000.0	0.0	0.0	0.0	0.0
IL3..middle_bridge		0.0	0.0	-1220000.0	1220000.0	0.0	0.0	0.0	0.0
IL4..back side		0.0	0.0	-1220000.0	1220000.0	0.0	0.0	0.0	0.0
IL5..At_forestay		0.0	0.0	-1220000.0	1220000.0	0.0	0.0	0.0	0.0
IL6..at_hinge_point		0.0	0.0	-2440000.0	2440000.0	0.0	0.0	0.0	0.0
IL7..9Trolley_ride		194000.0	0.0	0.0	194000.0	0.0	0.0	0.0	0.0
IL8..tip side_load		0.0	48500.0	0.0	48500.0	0.0	0.0	0.0	0.0
IL9..middle_bridge_side_load		0.0	48500.0	0.0	48500.0	0.0	0.0	0.0	0.0
IL10..backside_side_load		0.0	48500.0	0.0	48500.0	0.0	0.0	0.0	0.0
IL11..At_forestay_side_load		0.0	48500.0	0.0	48500.0	0.0	0.0	0.0	0.0
IL12..at_hinge_point_side_load		0.0	97000.0	0.0	97000.0	0.0	0.0	0.0	0.0
IL13..Crane_ride		0.0	504286.0	0.0	504286.0	0.0	0.0	0.0	0.0

# Plots Section

1


Press *Next* to navigate to the Plots section

Use *Navigation* alternatively

2

Select all Individual loads from the list

3

Press  to add Criteria Plot

✓ Edit '1..Report 1'

**Plots**  
Define Criteria, Contour and Output Vector plots. Criteria - element is colored based on a single value. Contour - element is colored based on corner data, typically used for stresses, strains. Output Vector - criteria plot on output vector.

**Navigation**  
First Page  
Model Setup  
Job Settings & Tools  
Tables  
**Plots**  
Standards


✓ Jobs 1..Job 1 Plot Type Individual Loads  
Load Sets  
Load Groups  
Expand Graph and Histogram ☐ Automatically sort tables and plots by result category

**2.**

Individual Loads	Plots
1..gravity	0
2..tip load	0
3..middle_bridge	0
4..back side	0
5..At_forestay	0
6..at_hinge_point	0
7..9Trolley_ride	0
8..tip side_load	0
9..middle_bridge_side_load	0
10..back_side_side_load	0
11..At_forestay_side_load	0
12..at_hinge_point_side_I...	0
13..Crane_ride	0

**3.**

Category	Point	Direction	View	Selection	Type
----------	-------	-----------	------	-----------	------



< Back 1. **Next >** OK Generate Go To Designer Close


Plots can be copied, edited in the same way as described in the tables section

# Add Criteria Plot

1

Select following parameters:  
*Category:* **Displacement**  
*Direction:* **Usum**  
*View:* **2..Front**


2

Press  to set the following limits:  
*Limits Type:* **Above Maximum**  
*Maximum:* **0.02**



3

Press **OK**

1.




Usum Displacement (All Entities, 2..Front)



Values less than 0.02 are displayed in element colors

# Add Contour Plot

1 Press  to add Contour Plot

Select following parameters:

*Category:* **Stress**


*Direction:* **Equivalent**

*Point:* **Total**


*View:* **1..Default View**

3 Press **OK**


2.



Equivalent Stress (All Entities, 1..Default View)



Individual Load Selection	13..Crane_ride	Parameter View	Stress Equivalent
Data Conversion	All Entities		1..Default View
	No Averaging, Corner		



Data Conversion is applied to plates and solids only




# Standards


1 Press **Next** to navigate to the Standards section

Use *Navigation* alternatively

2 Include Standards: **ON**

3 Press  to add Criteria Check Plot

Constants, characteristics, classifications or standard tables are disabled if no items exist of respective type



# Add Criteria Check Plot

Static Stress Check can be calculated over load groups only. Load Group is automatically selected as it is the only one in the project

1

Set the following settings:

*Parameters: All*


*Direction: Eqv.*

*Point of Interest: Total*


*Views: 2..Front, 3..Top*

2

Press OK





Absolute Eqv. Utilization Factor (LG1, All Entities, 2..Front)




Absolute equivalent utilization factor for front view is displayed


# Add Check Extreme Table

1 Press  to add Custom Check Table



2 Press  to add selection "All Entities"

3 Press OK



## Utilization Factor (LG1, All Entities)

Standard	1..Static stress check	Check Parameter	1..Static Stress Check
Load Group	1..Overall		Utilization Factor
Selection	All Entities		


Extreme	X	Y	Z	XY	YZ	ZX	Eqv.	Overall
Minimum								
Value	0.00			0.00			0.00	0.00
Element ID	284			520			284	284
Maximum								
Value	0.85			0.00			0.85	0.85
Element ID	131			521			131	131
Absolute								
Value	0.85			0.00			0.85	0.85
Element ID	131			521			131	131

Min/Max/Abs utilization factor is shown in the table together with the element Id where peak is located

# Generate Report

1

Press **Generate** to generate and open report in Microsoft Word



Add new or edit existing Report

Preview report structure and customize if necessary